


AIRPORT DIAGRAM

SE-4, 11 JUN 2026 to 09 JUL 2026



AIRPORT DIAGRAM

ATLANTA, GEORGIA HARTSFIELD/JACKSON ATLANTA INTL (ATL)

SE-4, 11 JUN 2026 to 09 JUL 2026

LANDING AIRCRAFT CAN EXPECT TO REMAIN ON TOWER FREQUENCY UNTIL SPECIFICALLY INSTRUCTED TO CONTACT GROUND CONTROL. CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES. READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

CAUTION: Pilots are advised not to mistake the marked pavement on the Rwy 10/28 and Twy SG Interstate highway overpasses for a taxiway.

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

D-ATIS ARR 119.65
DEP 125.55
ATLANTA TOWER
119.1 254.4 (RWY 08L-26R)
119.3 254.4 (RWY 09R-27L)
119.5 254.4 (RWY 10-28)
123.85 254.4 (RWY 09L-27R)
125.325 254.4 (RWY 08R-26L)
GND CON
121.9 254.4 (RWYS 08L-26R, 08R-26L)
121.65 (RWY 10-28)
121.75 (RWYS 09L-27R, 09R-27L)
118.1
CPDIC
PDC

JANUARY 2015
ANNUAL RATE OF CHANGE
0.1° W
VAR 5° W

Field Elevation 1026

CAUTION: Pilots are advised not to mistake the marked pavement on the Rwy 10/28 and Twy SG Interstate highway overpasses for a taxiway.

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES. READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

Ramp Frequencies:
Ramp 1 131.45
Ramp 2 131.85
Ramp 3 129.275
Ramp 4 130.075
Ramp 5 129.375
Ramp 6 131.375
Ramp 8 128.975
Ramp 9 131.875
Ramp 6N Snow and Ice 129.25
Ramp 6S Snow and Ice 131.375
Ramp 7 Snow and Ice 129.25
Ramp 20 Snow and Ice 129.25
Ramp 33 Snow and Ice 129.40
Non Movement Area 131.375